



## HEIZ- UND REGELTECHNIK HEATING AND CONTROLLING TECHNOLOGY

### HEIZER/TITANROHR | HEATER/TITANIUM TUBE

#### ART.-NR. | ART. NO.

537	Heizstab/Titanrohr/heater/titanium tube	50 W - 230 V/50 Hz
539	Heizstab/Titanrohr/heater/titanium tube	75 W - 230 V/50 Hz
542	Heizstab/Titanrohr/heater/titanium tube	100 W - 230 V/50 Hz
544	Heizstab/Titanrohr/heater/titanium tube	150 W - 230 V/50 Hz
546	Heizstab/Titanrohr/heater/titanium tube	200 W - 230 V/50 Hz
547	Heizstab/Titanrohr/heater/titanium tube	250 W - 230 V/50 Hz
548	Heizstab/Titanrohr/heater/titanium tube	300 W - 230 V/50 Hz
560	Heizstab/Titanrohr/heater/titanium tube	600 W - 230 V/50 Hz
621	Saugnapfhalter/vacuum cup holder	Ø 25 mm, 2 St./2 pcs.

### PTC-HEIZER/TITANROHR | PTC-HEATER/TITANIUM TUBE

#### ART.-NR. | ART. NO.

501	PTC-Heizstab/Titanrohr/ptc-heater/titanium tube	100 W - 230 V
502	PTC-Heizstab/Titanrohr/ptc-heater/titanium tube	200 W - 230 V
503	PTC-Heizstab/Titanrohr/ptc-heater/titanium tube	300 W - 230 V
506	PTC-Heizstab/Titanrohr/ptc-heater/titanium tube	600 W - 230 V
622	Saugnapfhalter/vacuum cup holder	Ø 12 mm, 2 St./2 pcs.

### TEMPERATURREGLER | THERMOSTAT

#### ART.-NR. | ART. NO.

113	TR2	2 m Fühlerkabel/sensor cable	max. 2000 W
1135M	TR2	5 m Fühlerkabel/sensor cable	max. 2000 W
1112	Fühlerkabel/sensor cable	Ersatzteil/spare part	2 m
1115	Fühlerkabel/sensor cable	Ersatzteil/spare part	5 m